

# Simplified Installation Instructions for Legacy (QC series) POU Filters

ATTACH TO FAUCET

SECURE WITH  
HOSE CLAMP

SECURE WITH  
HOSE CLAMP

3/8" x 30"  
Sink Supply

ATTACH TO COLD  
WATER LINE SHUT-OFF  
VALVE



4"

ALLOW ABOUT 4" BELOW CARTRIDGE SO YOU HAVE  
ROOM TO CHANGE THE CARTRIDGE NEXT YEAR

Use 3/8" X 30" flexible sink supply. (Measure first to make sure 30" is enough.)

- 1 - Mount filter bracket high enough to allow cartridge change
- 2 - Attach sink supply line to cold water line shut-off valve. Bring over to inlet (left) side of filter and cut it. Secure with hose clamp.
- 3 - Attach remaining section of supply line to faucet.
- 4 - Attach cut end to outlet (right) side of filter. Secure with hose clamp.
- 5- Lubricate O-ring of filter cartridge and install cartridge.

Turn the water back on and check for leaks. You're finished!

Enjoy your **ez Clear Water !**

If you want to use hard plumbing (copper) you may do so. The barbed fittings on each side of the filter screw out and may be replaced.

\* This is the simplified version of a Legacy installation. Please use common sense.

ezClearWater.com and Selecto are not responsible for water damage.